

GTR BLD Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
BLD	※	

GTR BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
BMS	※	

GTR_DIAG Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle			Model Year	
Europe	NISSAN GT-R			ALL	
Europe	NISSAN GT-R NISMO			ALL	
Japan	NISSAN GT-R			ALL	
Japan	NISSAN GT-R NISMO			ALL	
Middle and Near East	NISSAN GT-R			ALL	
Middle and Near East	NISSAN GT-R NISMO			ALL	
Middle and Near East	NISSAN GT-R(GCC)			ALL	
Middle and Near East	NISSAN GT-R(US)			ALL	
North America	NISSAN GT-R			ALL	
North America	NISSAN GT-R NISMO			ALL	
Latin America	NISSAN GT-R			ALL	
Latin America	NISSAN GT-R NISMO			ALL	
Far East	NISSAN GT-R			ALL	
Far East	NISSAN GT-R NISMO			ALL	
Oceania	NISSAN GT-R			ALL	
Oceania	NISSAN GT-R NISMO			ALL	
Africa	NISSAN GT-R			ALL	
Systemlist	EcuInfo	ReadCodes	EraseCodes	LiveData	Actuation
ECM (Engine Control Module)	●	●	●	●	●
TCM (Transmission Control Module)	●	●	●	●	●
ABS (Anti-lock Braking System)	●	●	●	●	●
SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
IC (Instrument cluster)	●	●	●	●	●
BCM (Body Control Module)	●	●	●	●	●
HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
EHS/PKB(Electronic Parking Brake)	●	●	●	●	●
EPS (Electronic Power Steering)	●	●	●	●	○
FSCM (Fuel System Control Modle)	●	●	●	○	●
E-SUS (Electric Suspension)	●	●	●	○	●
IPDM E/R(Intelligent Power Distribution Mudule E/R)	●	●	●	●	●
4WAS (4-Wheel Active Steering)	●	●	●	●	●
A-IVC(Renault common)	●	●	●	○	○
Accele Pedal Act	●	●	●	●	●
Active Engine Mount	○	○	●	○	○
ADCM	●	●	●	●	●
AFS (Adaptive Front Lighting System)	●	●	●	○	●
Air Pressure Monitor	●	●	●	●	●
AIRBAG2	●	●	●	●	○
All Mode Awd/4wd	●	●	●	●	●
AnC (Active noise Cancellation)	●	●	●	●	●
Auto Back Door	●	●	●	●	○
Auto Drive Position	●	●	●	○	●
Auto Slide Door	●	●	●	●	●
Auto Slide Door Right	●	●	●	●	●
Automatic Data Acquisition System (ADAS)	●	●	●	●	●

AVM (Around View Monitor)	●	●	●	○	●
Brake	●	●	●	●	●
BSW (Warning Of Lane Change)	●	●	●	○	●
Bypass Air Control (BAC)	●	●	●	●	○
CAn Gateway		●	●	●	●
CAn GATEWAY2	●	●	●	●	○
CAn GATEWAY3	●	●	●	●	○
CCS (Cruise Control System)	●	●	●	●	●
CHA (Charge)	●	●	●	○	●
Charger/PD Module	●	●	●	●	●
Chassis Control	●	●	●	●	●
CIU (Computer Interface Unit)	●	●	●	○	●
Cluster	●	●	●	○	●
Convertible Roof	●	●	●	●	●
DAST 1	●	●	●	●	○
DAST 2	●	●	●	●	○
Diff Lock	●	●	●	○	○
DIU (Digital Interface Unit)	○	●	○	○	○
E-4WD(4 Wheel Drive)	●	●	●	●	●
EMCM	●	●	●	○	●
Generator	●	●	●	●	○
Hands Free Module	●	●	●	●	●
HAS (Hill-start Assist System)	●	●	●	○	●
HICAS (High Capacity Actively Controlled Suspension)	●	●	●	●	●
High Beam Assist	●	●	●	●	●
HV Battery(High Voltage Battery)	●	●	●	●	●
HV Battery SubCPU	●	●	●	●	○
Hybrid System	●	●	●	●	●
Intelligent Cruise Control (ICC)	●	●	●	●	●
Intelligent Key	●	●	●	●	●
Lane Camera	●	●	●	●	●
Laser/Radar	●	●	●	●	●
MM COnn	●	●	●	○	○
Motor Control	●	●	●	●	○
Multi AV	●	●	●	●	●
Multi Display	○	●	●	○	●
nATS IMMU	●	●	●	○	●
PMAS	●	●	●	○	○
POP UP HOOD	●	●	●	○	○
Precrash Seatbelt	●	●	●	○	○
PTC Heater	●	●	●	○	○
RADIO	●	●	●	○	●
RAS (Rear Active Steering)/	●	●	●	●	●
Security Gateway Gen3	○	●	●	○	○
Shift	●	●	●	○	○
Side Obstacle Warning (Front Left)	●	●	●	○	○
Side Obstacle Warning (Front	●	●	●	○	○
Side Radar Left	●	●	●	●	●
Side Radar Right	●	●	●	●	●
Sonar	●	●	●	●	●
Sub Meter	○	●	●	○	○
Telematics	●	●	●	●	●
Vehicle Data Transmitter	●	●	●	○	○
VSP (Vehicle Sound for	●	●	●	○	●

GTR DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
DPF	※	

GTR DWR Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
DWR	※	

GTR EPB Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
EPB	※	

GTR ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
ETC	※	

GTR FPP Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
FPP	※	

GTR IDL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
IDL	※	

GTR INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
INJ	※	

GTR LAP Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
LAP	※	

GTR OIL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
OIL	※	

GTR SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
SAS	※	

GTR SIT Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
SIT	※	

GTR ACS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Model Year
Europe	NISSAN GT-R	ALL
Europe	NISSAN GT-R NISMO	ALL
Japan	NISSAN GT-R	ALL
Japan	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R	ALL
Middle and Near East	NISSAN GT-R NISMO	ALL
Middle and Near East	NISSAN GT-R (GCC)	ALL
Middle and Near East	NISSAN GT-R (US)	ALL
North America	NISSAN GT-R	ALL
North America	NISSAN GT-R NISMO	ALL
Latin America	NISSAN GT-R	ALL
Latin America	NISSAN GT-R NISMO	ALL
Far East	NISSAN GT-R	ALL
Far East	NISSAN GT-R NISMO	ALL
Oceania	NISSAN GT-R	ALL
Oceania	NISSAN GT-R NISMO	ALL
Africa	NISSAN GT-R	ALL
Function Type	Support	
ACS	※	