

RENAULT_SAMSUNG ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | ETC |
|------------------------|-----|
| CAPTUR/QM3/KABIN | ● |
| CLIO IV | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| TALISMAN/SM6 | ● |

ETC Function List

Programming Throttle Limits

RENAULT_SAMSUNG INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | INJ |
|------------------------|-----|
| CAPTUR/QM3/KABIN | ● |
| CLIO IV | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| TALISMAN/SM6 | ● |

INJ Function List

Injector Adaptives

Cylinder Injector Code

Injection Pump Adaptatives

Fuel Pump Programming

Injector Adaptives No 1, 2, 3, 4

Enter Injector Codes

Enter Injector Calibration Data

RENAULT_SAMSUNG ODO Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | ODO |
|------------------------|-----|
| CAPTUR/QM3/KABIN | ● |
| CLIO IV | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| SM7 - L47 | ● |
| XM3 | ● |

ODO Function List

Language Configuration

Language Version

RENAULT_SAMSUNG OIL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | OIL |
|------------------------|-----|
| KOLEOS II CN/QM6 CN | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| SM7 - L47 | ● |
| TALISMAN/SM6 | ● |

OIL Function List

| |
|-----------------------------------------------|
| Distance Before Next Oil Change |
| Oil Change Interval In Km |
| Oil Change Range: Current Value In Km |
| Oil Change Interval In Months |
| Oil Change Range:current Value In Months |
| Oil Change Interval In Miles |
| Oil Change Range:current Value In Miles |
| Personalised Oil Change Frequency |
| Distance Before Next Oil Change Configuration |

RENAULT_SAMSUNG SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | SAS |
|------------------------|-----|
| CAPTUR/QM3/KABIN | ● |
| CLIO IV | ● |
| KOLEOS II CN/QM6 CN | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| SM7 - L47 | ● |
| TALISMAN/SM6 | ● |

SAS Function List

Steering Wheel Angle Offset Sensor

Steering Wheel Angle Sensor Programming

Steering Wheel Angle Sensor

Steering Angle Sensor Initialisation

Steering Angle Offset

RENAULT_SAMSUNG TPM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | TPM |
|------------------------|-----|
| KOLEOS II CN/QM6 CN | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| SM7 - L47 | ● |
| TALISMAN/SM6 | ● |

TPM Function List

Enter Recommended Pressures

Programming A Valve Code

Programming The Codes Of The Four Valves

Read Valve Set And Memorised Codes

RENAULT_SAMSUNG BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | BMS |
|------------------------|-----|
| NEW SM3/FLUENCE/MEGANE | ● |
| TWIZY | ● |

BMS Function List

Autonomy Battery

Battery Corrosion Counter

Calculate Battery Wear Counters

Corrosion Battery Counter Memorised

Corrosion Battery Counter Estimated

Battery Cycle Counter Memorised

Battery Cycle Counter Estimated

Battery Cycle Counter

Timed + Batt

100 Ah Traction Battery

Change Battery Compartment

Battery Filling Reinitialisation

Internal Battery

Traction Battery Relay

RENAULT_SAMSUNG Diagnostic Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | Systemlist | EcuInfo. | ReadCodes | EraseCodes | LiveData | ActTest |
|--------------------------|-----------------------------------|----------|-----------|------------|----------|---------|
| CAPTUR/ QM3/ KABIN | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Lighting | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Communications Unit | ● | ● | ● | ● | ● |
| | Hands Free Kit | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ○ |
| | Radio | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ○ |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| CLIO IV | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Lighting | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Communications Unit | ● | ● | ● | ● | ○ |
| | Hands Free Kit | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ○ |
| | Radio | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| | Variable P.A.S | ● | ● | ● | ● | ● |
| KOLEOS II CN/ QM6 CN | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | 4 Wheels Drive | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Front Camera | ● | ● | ● | ● | ○ |
| | Front Radar | ● | ● | ● | ● | ○ |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Power Back Door | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ○ |
| UCH | ● | ● | ● | ● | ● | |
| UPC | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ● | |

| | | | | | | |
|----------------------------|-----------------------------------|---|---|---|---|---|
| KOLEOS II/ QM6 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | 4 Wheels Drive | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Front Camera | ● | ● | ● | ● | ○ |
| | Front Radar | ● | ● | ● | ● | ○ |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Power Back Door | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ○ |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| Urea Dosing Control Module | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| KOLEOS/ QM5 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ○ |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | TPM (Tire Pressure Monitoring) | ● | ● | ● | ● | ● |
| | Auto Front Lighting | ● | ● | ● | ● | ● |
| | Discharge Lamp | ● | ● | ● | ● | ● |
| | 4 Wheels Drive | ● | ● | ● | ● | ○ |
| | Amplifier | ● | ● | ● | ● | ● |
| | Blind Spot Detection | ● | ● | ● | ● | ● |
| | Communications Unit | ● | ● | ● | ※ | ○ |
| | Multimed. Connection | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| LATITUDE/ SM5 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | Lighting | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Blind Spot Detection | ● | ● | ● | ● | ○ |
| | Communications Unit | ● | ● | ● | ● | ● |
| | Driver's Door | ● | ● | ● | ● | ● |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimed. Connection | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ○ |
| | Passenger's Door | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Right-Hand Door | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| Telematic Ctrl Unit | ● | ● | ● | ● | ● | |
| UCH | ● | ● | ● | ● | ● | |
| UPC | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ● | |

| | | | | | | |
|--------------------------------|-----------------------------------|---|---|---|---|---|
| MEGANE IV SEDAN | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Front Camera | ● | ● | ● | ● | ● |
| | Front Radar | ● | ● | ● | ● | ○ |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ○ |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| | Urea Dosing Control Module | ● | ● | ● | ● | ● |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| NEW SM3/ FLUENCE/ MEGANE | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | PEB | ● | ● | ● | ● | ○ |
| | Parking Brake | ● | ● | ● | ● | ● |
| | BMS | ● | ● | ● | ● | ○ |
| | BMS Safety | ● | ● | ● | ● | ● |
| | Lighting | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | BCB | ● | ● | ● | ● | ● |
| | Blind Spot Detection | ● | ● | ● | ● | ● |
| | Communications Unit | ● | ● | ● | ● | ● |
| | Driver's Door | ● | ● | ● | ● | ● |
| | EVC | ● | ● | ● | ● | ● |
| | Multimed. Connection | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ○ |
| | Radio | ● | ● | ● | ● | ● |
| Sunroof Control Unit | ● | ● | ● | ● | ● | |
| Telematic Ctrl Unit | ● | ● | ● | ● | ● | |
| Tracker | ● | ● | ● | ● | ● | |
| UCH | ● | ● | ● | ● | ● | |
| UPC | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| SAFRANE2.0/ SM5 - DF | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ○ | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | Discharge Lamp | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| SAFRANE2.3/ SM7 - LF | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | Discharge Lamp | ● | ● | ● | ● | ○ |
| | Seat Management | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| SCALA/ SM3-CF | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | Parking Assistance | ● | ● | ● | ● | ● |
| SM3 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| SM5 | Airbag | ● | ● | ● | ● | ● |
| | Gas Inj | ● | ● | ● | ● | ● |

| | | | | | | |
|----------------------------|-----------------------------------|---|---|---|---|---|
| SM5 - EX | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | Discharge Lamp | ● | ● | ● | ● | ● |
| | Parking Assistance | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| UCH | ● | ● | ● | ● | ● | |
| SM7 | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | Discharge Lamp | ● | ● | ● | ● | ● |
| | Parking Assistance | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ○ |
| UCH | ● | ● | ● | ● | ● | |
| SM7 - L47 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | Lighting | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Blind Spot Detection | ● | ● | ● | ● | ○ |
| | Communications Unit | ● | ● | ● | ● | ● |
| | Driver's Door | ● | ● | ● | ● | ● |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimed. Connection | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Passenger's Door | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Right-Hand Door | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| UCH | ● | ● | ● | ● | ● | |
| UPC | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ○ | |
| TALISMAN/SM6 | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-lock Braking System) | ● | ● | ● | ● | ● |
| | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | Parking Brake | ● | ● | ● | ● | ● |
| | 4 Wheels Steering | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ● |
| | Front Camera | ● | ● | ● | ● | ● |
| | Front Radar | ● | ● | ● | ● | ● |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | Piloted Suspension | ● | ● | ● | ● | ○ |
| | Power Back Door | ● | ● | ● | ● | ● |
| | Radio | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ○ |
| | Telematic Ctrl Unit | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| UPC | ● | ● | ● | ● | ● | |
| Urea Dosing Control Module | ● | ● | ● | ● | ● | |
| Variable P.A.S | ● | ● | ● | ● | ● | |
| TWIZY | Airbag | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | BMS | ● | ● | ● | ● | ● |
| | Adaptation Unit | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| | ECM (Engine Control Module) | ● | ● | ● | ● | ● |
| | TCM (Transmission Control Module) | ● | ● | ● | ● | ● |
| | ABS (Anti-Lock Braking System) | ● | ● | ● | ● | ● |

| | | | | | | |
|-----|------------------------------------------------|---|---|---|---|---|
| XM3 | SRS (Supplemental Inflatable Restraint System) | ● | ● | ● | ● | ● |
| | IC (Instrument Cluster) | ● | ● | ● | ● | ● |
| | AC (Air Conditioning) | ● | ● | ● | ● | ● |
| | BMS 12V | ● | ● | ● | ● | ※ |
| | Parking Brake | ● | ● | ● | ● | ● |
| | Parking Prox Can | ● | ● | ● | ● | ● |
| | UCH | ● | ● | ● | ● | ● |
| | UPC | ● | ● | ● | ● | ● |
| | BSG | ● | ● | ● | ● | ※ |
| | EVC | ● | ● | ● | ● | ※ |
| | Central Gateway | ● | ● | ● | ● | ※ |
| | Check Chassis | ● | ● | ● | ● | ○ |
| | Brake Booster | ● | ● | ● | ● | ● |
| | Amplifier | ● | ● | ● | ● | ※ |
| | Communications Unit | ● | ● | ● | ● | ○ |
| | Driving Assistance Supervisor | ● | ● | ● | ● | ● |
| | Front Camera | ● | ● | ● | ● | ● |
| | Front Radar | ● | ● | ● | ● | ● |
| | Hands-Free Module | ● | ● | ● | ● | ※ |
| | Left Rear Side Radar | ● | ● | ● | ● | ● |
| | Right Rear Side Radar | ● | ● | ● | ● | ● |
| | Left-Hand Door | ● | ● | ● | ● | ● |
| | Multimedia Interface | ● | ● | ● | ● | ※ |
| | Radio | ● | ● | ● | ● | ● |
| | Seat Management | ● | ● | ● | ● | ● |
| | Supervisor | ● | ● | ● | ● | ※ |
| | Telematic Control Unit | ● | ● | ● | ● | ● |
| | Telephone Induction Charger | ● | ● | ● | ● | ● |
| | Variable P. A. S | ● | ● | ● | ● | ● |

RENAULT_SAMSUNG DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | DPF |
|------------------------|-----|
| CAPTUR/QM3/KABIN | ● |
| CLIO IV | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| TALISMAN/SM6 | ● |

DPF Function List

| |
|----------------------------------------------|
| Particle Filter Pressure Diff. Sensor |
| Adaptives After Replacing Cabin Filter |
| Cabin Filter Regeneration |
| Particle Filter Relative Pressure Sensor |
| Adaptives After Regenerating Particle Filter |
| Particle Filter Adaptives |
| Particle Filter |
| Particle Filter Regeneration |

RENAULT_SAMSUNG EPB Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

| Model | EPB |
|------------------------|-----|
| KOLEOS II CN/QM6 CN | ● |
| KOLEOS II/QM6 | ● |
| KOLEOS/QM5 | ● |
| LATITUDE/SM5 | ● |
| MEGANE IV SEDAN | ● |
| NEW SM3/FLUENCE/MEGANE | ● |
| SM7 - L47 | ● |
| TALISMAN/SM6 | ● |

EPB Function List

Electrical Parking Brake Apply and Release