

RollsRoyce Diagnostic Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

RollsRoyce Car List

Series	Development code	Sales designation
Rolls-Royce	RR1	Phantom
Rolls-Royce	RR1	Phantom Extended Wheelbase
Rolls-Royce	RR11	ALL
Rolls-Royce	RR12	ALL
Rolls-Royce	RR2	ALL
Rolls-Royce	RR3	ALL
Rolls-Royce	RR31	ALL
Rolls-Royce	RR4	GHOST
Rolls-Royce	RR4	Ghost Extended Wheelbase
Rolls-Royce	RR5	ALL
Rolls-Royce	RR6	ALL

RollsRoyce Ecu List

System Name	Ecu Info	Read Codes	Erase Codes	Live Data	Act
AB [Airbag]	●	●	●	●	●
ABS [Antilock brake system FTE]	●	●	●	●	●
ABS [Antilock brake system Integral-ABS FTE]	●	●	●	●	●
ABS [Antilock braking systemABS1]	●	●	●	●	●
ABS [Antilock braking systemABS2]	●	●	●	●	●
ABS [Antilock braking systemABS5]	●	●	●	●	●
ABS [Antilock braking systemMK4G]	●	●	●	●	●
ABS [Bosch antilock brake system]	●	●	●	●	●
ABS [Conti antilock brake system]	●	●	●	●	●
ABS [Stability controlMK20]	●	●	●	●	●
ABS-DSC [Stability system EBC_450]	●	●	●	●	●
ABS-DSC [Stability system MK60]	●	●	●	●	●
ACC [Active cruise control]	●	●	●	●	●
ACP [Audio Control Panel]	●	●	●	●	●
ACSM [Crash safety module]	●	●	●	●	●
ACSM-MRS [Crash safety module/multiple restraint system]	●	●	●	●	●
ADP [Audio Display Panel]	●	●	●	●	●
ADS	●	●	●	●	●
AEP	●	●	●	●	●
AGS [Transmission control]	●	●	●	●	●
AHL [Adaptive Headlights/headlight beam throw adjustment]	●	●	●	●	●
AHL [Adaptive headlight/headlight beam throw adjustment]	●	●	●	●	●
AHM [Trailer module]	●	●	●	●	●
AIC [Automatic Interval Control]	●	●	●	●	●
AL [Active steering]	●	●	●	●	●
ALBBF [Active backrest width, front passenger]	●	●	●	●	●
ALBFA [Active backrest width, driver]	●	●	●	●	●

AMP [Hi-Fi amplifier]	●	●	●	●	●
AMP [Top HiFi amplifier]	●	●	●	●	●
AMPH [Hi-Fi amplifier]	●	●	●	●	●
AMPT [Top HiFi amplifier]	●	●	●	●	●
ANT [Aerial tuner]	●	●	●	●	●
APM [Hybrid DC/DC converter]	●	●	●	●	●
ARS [Dynamic drive]	●	●	●	●	●
ASC [Stability controlABD5]	●	●	●	●	●
ASC [Stability controlASC57]	●	●	●	●	●
ASC [Stability controlASC5D]	●	●	●	●	●
ASC [Stability controlASC5]	●	●	●	●	●
ASC [Stability controlMK20]	●	●	●	●	●
ASC [Stability controlMK4US]	●	●	●	●	●
ASC [Stability controlMK4]	●	●	●	●	●
ASC [Stability control]	●	●	●	●	●
ASD [Active sound design]	●	●	●	●	●
ASK [Audio system controller]	●	●	●	●	●
AUDIO [Audio system]	●	●	●	●	●
Automatic climate control	●	●	●	●	●
BATT48 [Battery electronics 48 volt]	●	●	●	●	●
BC [On-board computer]	●	●	●	●	●
BCM [Battery monitoring module]	●	●	●	●	●
BCO [On-board computer]	●	●	●	●	●
BCO/MID [On-board computer/MID]	●	●	●	●	●
BDC [Body Domain Controller]	●	●	●	●	●
BIT [Basic interface telephone]	●	●	●	●	●
BM [On-board monitor control panel]	●	●	●	●	●
BM [On-board monitor, Top navigation]	●	●	●	●	●
BM [On-board monitor, widescreen]	●	●	●	●	●
BM [On-board monitor]	●	●	●	●	●
BZM [Centre console control panel]	●	●	●	●	●
BZMF [Control centre, rear compartment centre armrest]	●	●	●	●	●
CA [Comfort Access]	●	●	●	●	●
CANALLG	●	●	●	●	●
CANWAY	●	●	●	●	●
CAN_PL2	●	●	●	●	●
CAS [Car Access System]	●	●	●	●	●
CBX-ECALL [Combox emergency call]	●	●	●	●	●
CBX-MEDIA [Combox Multimedia]	●	●	●	●	●
CCC-A [Applications]	●	●	●	●	●
CCC-ANT [Aerial tuner]	●	●	●	●	●
CCC-ASK [Audio system controller]	●	●	●	●	●
CCC-BO [User interface]	●	●	●	●	●
CCC-GW [Gateway]	●	●	●	●	●
CCM [Check control module]	●	●	●	●	●
CD [Control display]	●	●	●	●	●
CD-GW [Control Display (Gateway)]	●	●	●	●	●
CDC [CD changer]	●	●	●	●	●
CDM [Coach door module]	●	●	●	●	●
CDML [coach door module, left]	●	●	●	●	●
CDMR [coach door module, right]	●	●	●	●	●
CEM [Clean Energy Module]	●	●	●	●	●

CHAMP [Central head unit and multimedia platform]	●	●	●	●	●
CHAMP-BO [User interface]	●	●	●	●	●
CHAMP-GW [Gateway]	●	●	●	●	●
CHRONO [Chronometer]	●	●	●	●	●
CIC [Car Information Computer]	●	●	●	●	●
CIC-GW [Gateway]	●	●	●	●	●
CID [Central Information Display]	●	●	●	●	●
CID [Central information display]	●	●	●	●	●
CIM [Chassis integration module]	●	●	●	●	●
CNAV [Navigation system China]	●	●	●	●	●
CON [Controller]	●	●	●	●	●
CPM [CPM]	●	●	●	●	●
CSM [Car sharing module]	●	●	●	●	●
CTM [Convertible-top module]	●	●	●	●	●
CVM [Convertible-top module]	●	●	●	●	●
CVM2 [Convertible top module 2]	●	●	●	●	●
Carb	●	●	●	●	●
Complete vehicle	●	●	●	●	●
Convenience charging electronics	●	●	●	●	●
DAB [DAB tuner]	●	●	●	●	●
DCS [Driver Camera System]	●	●	●	●	●
DDC [Electronic suspension adjustment]	●	●	●	●	●
DDE [Diesel electronics US]	●	●	●	●	●
DDE [Diesel electronics master]	●	●	●	●	●
DDE [Diesel electronics slave]	●	●	●	●	●
DDE [Diesel fuel electronics]	●	●	●	●	●
DDE [Digital diesel electronics]	●	●	●	●	●
DDE2 [Diesel electronics slave]	●	●	●	●	●
DIA_DOSE	●	●	●	●	●
DKG [Electronic transmission control]	●	●	●	●	●
DKG [Transmission control]	●	●	●	●	●
DME [Digital Motor Electronics]	●	●	●	●	●
DME [Digital engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine control]	●	●	●	●	●
DME [Engine electronics H2, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics, cylinder bank 1]	●	●	●	●	●
DME [Engine electronics]	●	●	●	●	●
DME2 [Digital Engine Electronics, bank 2]	●	●	●	●	●
DME2 [Digital Motor Electronics, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics H2, cylinder bank 2]	●	●	●	●	●
DME2 [Engine electronics, cylinder bank 2]	●	●	●	●	●
DSC [Dynamic Stability Control DSC8 Plus]	●	●	●	●	●
DSC [Dynamic Stability Control]	●	●	●	●	●
DSC [Dynamic stability control DSC5.7]	●	●	●	●	●
DSC [Dynamic stability control DSC8 PLUS]	●	●	●	●	●
DSC [Dynamic stability controlDSC8]	●	●	●	●	●
DSC [Dynamic stability controlEHB3]	●	●	●	●	●
DSC [Dynamic stability controlMK60 E5]	●	●	●	●	●

DSC [Dynamic stability controlMK60]	●	●	●	●	●
DSC [Stability controlDSC3]	●	●	●	●	●
DSC [Stability controlDSC57]	●	●	●	●	●
DSC [Stability controlDSC5]	●	●	●	●	●
DSC [Stability controlMK20]	●	●	●	●	●
DSM [Hybrid parking lock]	●	●	●	●	●
DSP [DSP control panel]	●	●	●	●	●
DSP [Digital sound processor]	●	●	●	●	●
DVDC [DVD changer]	●	●	●	●	●
DWA [Anti-theft alarm system]	●	●	●	●	●
DWA-RDC [Anti-theft alarm system/tyre pressure control]	●	●	●	●	●
EARSH [Rear electric active roll stabilisation]	●	●	●	●	●
EARSV [Front electric active roll stabilisation]	●	●	●	●	●
EDC [Electronic Damper Control K]	●	●	●	●	●
EDC [Electronic Damper Control]	●	●	●	●	●
EDC [Vertical Dynamics Management]	●	●	●	●	●
EDCSHL [Damper satellite, rear left]	●	●	●	●	●
EDCSHR [Damper satellite, rear right]	●	●	●	●	●
EDCSVL [Damper satellite, front left]	●	●	●	●	●
EDCSVR [Damper satellite, front right]	●	●	●	●	●
EDIC	●	●	●	●	●
EDME [Electrical Digital Motor Electronics]	●	●	●	●	●
EGS [Electronic transmission control]	●	●	●	●	●
EGS [Transmission control]	●	●	●	●	●
EHC [- 1-axle air suspension]	●	●	●	●	●
EHC [- Axle air suspension]	●	●	●	●	●
EHC [2-axle air suspension]	●	●	●	●	●
EHC [Electronic ride height control]	●	●	●	●	●
EHC2 [2-axle air suspension]	●	●	●	●	●
EHC2 [Electronic ride height control]	●	●	●	●	●
EHKS [Electro-hydraulic centre stand]	●	●	●	●	●
EHPS [Electro-hydraulic power steering]	●	●	●	●	●
EKK [Electric A/C compressor]	●	●	●	●	●
EKPS [Electronic fuel pump control module]	●	●	●	●	●
EKPS [Fuel pump control module]	●	●	●	●	●
ELV [Electric steering lock]	●	●	●	●	●
ELV [Electrical steering column adjustment]	●	●	●	●	●
EMALI [Electric motor-driven reel, left]	●	●	●	●	●
EMARE [Electric motor-driven reel, right]	●	●	●	●	●
EME [Electrical machine electronics]	●	●	●	●	●
EMF [Parking brake]	●	●	●	●	●
EML [Electronic engine power control]	●	●	●	●	●
EMPI [Hybrid oil pump control unit]	●	●	●	●	●
ENS [Ethernet switch]	●	●	●	●	●
EPS [Electronic Power Steering]	●	●	●	●	●
EPS [electromechanical power steering]	●	●	●	●	●
ESA [Electronic suspension adjustment]	●	●	●	●	●
EWS [Electronic immobiliser 2]	●	●	●	●	●
EWS [Electronic immobiliser 3D]	●	●	●	●	●
EWS [Electronic immobiliser 3]	●	●	●	●	●

EWS [Electronic immobiliser]	●	●	●	●	●
Electrical machine electronics	●	●	●	●	●
Engine electronics	●	●	●	●	●
F01BN2K	●	●	●	●	●
FADP [Rear compartment audio display panel]	●	●	●	●	●
FBI [Flexible Bus Interface]	●	●	●	●	●
FBZV [Radio remote control]	●	●	●	●	●
FCON [Rear-compartment controller]	●	●	●	●	●
FD [Rear monitor]	●	●	●	●	●
FD2 [Rear compartment display 2]	●	●	●	●	●
FD2 [Rear display 2]	●	●	●	●	●
FEM [Front electronic module]	●	●	●	●	●
FGB [Rear compartment blower]	●	●	●	●	●
FGR [Cruise control]	●	●	●	●	●
FID [Rear passenger compartment multi-information display]	●	●	●	●	●
FKA [Automatic rear air-conditioning system]	●	●	●	●	●
FKA [Rear compartment heating and air conditioning system]	●	●	●	●	●
FKA [Rear-compartment air conditioning]	●	●	●	●	●
FLA [High-beam assistant]	●	●	●	●	●
FLEL [Frontal Light Electronics Left]	●	●	●	●	●
FLER [Frontal Light Electronics Right]	●	●	●	●	●
FMBT [Rear-compartment monitor]	●	●	●	●	●
FRM [Driver's side footwell module]	●	●	●	●	●
FRM [Footwell module]	●	●	●	●	●
FRS [Front radar sensor]	●	●	●	●	●
FRSF [Long-distance range front radar sensor]	●	●	●	●	●
FZD [Roof function centre]	●	●	●	●	●
FZGIDENT	●	●	●	●	●
GHAS [Adjusted limited slip differential]	●	●	●	●	●
GHAS [regulated rear axle differential lock]	●	●	●	●	●
GM [Basic module (BCL)]	●	●	●	●	●
GM [Basic module (BCO)]	●	●	●	●	●
GM [Basic module control unit]	●	●	●	●	●
GM [General Module 5]	●	●	●	●	●
GM [General module III]	●	●	●	●	●
GMS [Basic module satellite]	●	●	●	●	●
GMSF [Basic module special vehicle]	●	●	●	●	●
GR [Cruise control]	●	●	●	●	●
GRPLIST	●	●	●	●	●
GWS [Gear selector switch]	●	●	●	●	●
GZAL [Targeted illumination, left]	●	●	●	●	●
GZAR [Targeted illumination, right]	●	●	●	●	●
HCP [Hybrid master control unit]	●	●	●	●	●
HIM [Hybrid Interface Module]	●	●	●	●	●
HKA [Rear automatic climate control]	●	●	●	●	●
HKFM [Tailgate function module]	●	●	●	●	●
HKL [Automatic luggage compartment lid actuation]	●	●	●	●	●
HKL [Luggage compartment lid module]	●	●	●	●	●
HRSNL [Rear radar sensor near range left]	●	●	●	●	●

HRSNR [Rear radar sensor near range right]	●	●	●	●	●
HSR [Rear axle slip angle control]	●	●	●	●	●
HU-B [HU-B]	●	●	●	●	●
HU-H [Headunit High]	●	●	●	●	●
HUD [Head-Up Display]	●	●	●	●	●
IBOC [Digital tuner US]	●	●	●	●	●
ICM [Integrated chassis management]	●	●	●	●	●
IFR	●	●	●	●	●
IHKA [Automatic climate control]	●	●	●	●	●
IHKA [Integrated automatic heating / air conditioning system]	●	●	●	●	●
IHKR [Heating/air conditioning control]	●	●	●	●	●
IHKS [Heating/air conditioning control]	●	●	●	●	●
IHR [Heating control]	●	●	●	●	●
IHS [Heating control]	●	●	●	●	●
IHS [Heating/air conditioning control]	●	●	●	●	●
IKE [Instrument panel]	●	●	●	●	●
ILM [Integrated charging module]	●	●	●	●	●
IPOD [iPod interface]	●	●	●	●	●
IR [Infrared compact locking system]	●	●	●	●	●
IR [Radio/infrared locking system]	●	●	●	●	●
IRIS [Integrated radio information system]	●	●	●	●	●
JBE [Junction Box Electronics]	●	●	●	●	●
JBIT [Japan basic interface telephone 2]	●	●	●	●	●
JBIT [Japan basic interface telephone]	●	●	●	●	●
JNAV [Navigation, Japan]	●	●	●	●	●
KAFAS [Camera-based driver assist system]	●	●	●	●	●
KBM [Body general module]	●	●	●	●	●
KFS [Radiator figure control]	●	●	●	●	●
KGM [Body Gateway Module]	●	●	●	●	●
KHI [Headphones interface]	●	●	●	●	●
KLE [Charging interface module]	●	●	●	●	●
KLE [Convenience charging electronics]	●	●	●	●	●
KNAV [Navigation system Korea]	●	●	●	●	●
KOMBI [Instrument cluster RR]	●	●	●	●	●
KOMBI [Instrument panel control unitRR 2]	●	●	●	●	●
KOMBI [Instrument panel]	●	●	●	●	●
KOMBI2 [Additional instruments]	●	●	●	●	●
LCM [Lights/check module A]	●	●	●	●	●
LCM [Lights/check module III]	●	●	●	●	●
LCM [Lights/check module II]	●	●	●	●	●
LCM [Lights/check module IV]	●	●	●	●	●
LCM [Lights/check module]	●	●	●	●	●
LDM [Longitudinal dynamics management]	●	●	●	●	●
LEM [Light effect manager]	●	●	●	●	●
LHML [LED main light module, left]	●	●	●	●	●
LHMR [LED main light module, right]	●	●	●	●	●
LIM [Charging interface module]	●	●	●	●	●
LM [Light module]	●	●	●	●	●
LMV [Longitudinal torque distribution]	●	●	●	●	●
LRA [Headlight beam throw adjustment]	●	●	●	●	●
LRR [Long range radar]	●	●	●	●	●

LSZ [Light switch cluster]	●	●	●	●	●
LWS [Steering angle sensor]	●	●	●	●	●
M-ASK-BO [User interface]	●	●	●	●	●
M-ASK-GW [Gateway]	●	●	●	●	●
M-ASK-NAV [Navigation system]	●	●	●	●	●
MCPA [Hybrid electric motor control unit 1]	●	●	●	●	●
MCPB [Hybrid electric motor control unit 2]	●	●	●	●	●
MESSEMOD	●	●	●	●	●
MFL [Multifunction steering wheelE38]	●	●	●	●	●
MFL [Multifunction steering wheel]	●	●	●	●	●
MID [Multi-information display]	●	●	●	●	●
MIR [Multi-information radio]	●	●	●	●	●
MJOY [MINI joystick]	●	●	●	●	●
MMB [Multimedia box]	●	●	●	●	●
MOST [Bus system analysis]	●	●	●	●	●
MPM [Micro-power module]	●	●	●	●	●
MRK24	●	●	●	●	●
MRKH2	●	●	●	●	●
MRS [Multiple restraint system]	●	●	●	●	●
NAR [Navigation radio]	●	●	●	●	●
NAV [Navigation system]	●	●	●	●	●
NVE [Night vision electronics]	●	●	●	●	●
NVK [Night Vision Camera]	●	●	●	●	●
OBD	●	●	●	●	●
OC3_FLSH	●	●	●	●	●
OC3_UPD	●	●	●	●	●
OPPS	●	●	●	●	●
PCU [Power Control Unit]	●	●	●	●	●
PCU48 [Power Control Unit 48 volt]	●	●	●	●	●
PCode [Reporting mit CARBPR (California Air Resources Board)]	●	●	●	●	●
PDC [Park distance control]	●	●	●	●	●
PM [Power module]	●	●	●	●	●
PMA [Parking manoeuvre assistant]	●	●	●	●	●
PMA [Parking manoeuvring assistant]	●	●	●	●	●
QMVH [Rear axle lateral torque distribution]	●	●	●	●	●
QMVH [Transmission control]	●	●	●	●	●
R56	●	●	●	●	●
RAD [Radio]	●	●	●	●	●
RAD2 [Radio 2]	●	●	●	●	●
RAD2-GW [Gateway]	●	●	●	●	●
RADIO [Radio-CD player]	●	●	●	●	●
RAM [Receiver audio module]	●	●	●	●	●
RBT [Radio operating unit]	●	●	●	●	●
RCC [Radio clock module]	●	●	●	●	●
RDC [Tyre Pressure Monitor]	●	●	●	●	●
RDC [Tyre pressure control]	●	●	●	●	●
RDME [Range extender digital engine electronics]	●	●	●	●	●
REM [Rear electronic module]	●	●	●	●	●
REMA LI [Reversible electromotive automatic reel, left]	●	●	●	●	●
REMARE [Reversible electromotive automatic reel, right]	●	●	●	●	●

REME [Range extender electrical machine electronics]	●	●	●	●	●
RFH [Reverser]	●	●	●	●	●
RFK [Reversing camera]	●	●	●	●	●
RLMAL [Rear light module outer left]	●	●	●	●	●
RLMAR [Rear light module outer right]	●	●	●	●	●
RLMIL [Rear light module inner left]	●	●	●	●	●
RLMIR [Rear light module inner right]	●	●	●	●	●
RLS [Rain/light sensor]	●	●	●	●	●
RLS [Rain/light solar sensor]	●	●	●	●	●
RPA [Run Flat Indicator]	●	●	●	●	●
RR1_2020	●	●	●	●	●
RSE [Rear seat entertainment system]	●	●	●	●	●
SAS [Optional extra system]	●	●	●	●	●
SASL [A-pillar satellite]	●	●	●	●	●
SASR [A-pillar satellite, right]	●	●	●	●	●
SBA [Hybrid brake actuation changeover]	●	●	●	●	●
SBBF [Front passenger seat occupancy]	●	●	●	●	●
SBE [Seat occupancy detection]	●	●	●	●	●
SBSL [B-pillar satellite, left]	●	●	●	●	●
SBSR [B-pillar satellite, right]	●	●	●	●	●
SCR [Selective Catalytic Reduction]	●	●	●	●	●
SDARS [Satellite tuner (US)]	●	●	●	●	●
SEC [Auxiliary control unit]	●	●	●	●	●
SEC2 [Auxiliary control unit 2]	●	●	●	●	●
SES [Voice control]	●	●	●	●	●
SFZ [Satellite, vehicle centre]	●	●	●	●	●
SG-FD [Rear-compartment display control unit]	●	●	●	●	●
SG-FD-GW [Control unit for rear compartment display (gateway)]	●	●	●	●	●
SGM-SIM [Safety and gateway module (SIM)]	●	●	●	●	●
SGM-ZGM [Safety and gateway module]	●	●	●	●	●
SGR48 [Starter motor generator 48 volt]	●	●	●	●	●
SHD [Panorama glass roof]	●	●	●	●	●
SHD [Slide/tilt sunroof]	●	●	●	●	●
SHD [Sunroof module]	●	●	●	●	●
SHZH [Indep./aux. heater]	●	●	●	●	●
SIM [Safety and Information Module]	●	●	●	●	●
SINE [Anti-theft alarm system]	●	●	●	●	●
SINE [siren and tilt alarm sensor]	●	●	●	●	●
SLM [Seat/steering column memory]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 4-channel]	●	●	●	●	●
SM/LSM [Mirror/sea/backrest memory, 6-channel]	●	●	●	●	●
SMB [Easy entry, front passenger]	●	●	●	●	●
SMB [Seat memory for front passenger]	●	●	●	●	●
SMB [Seat memory, front passenger]	●	●	●	●	●
SMBF [Front passenger seat module]	●	●	●	●	●
SMBFH [Rear passenger's side seat module]	●	●	●	●	●
SMBFH [rear passenger seat module]	●	●	●	●	●
SME [Battery management electronics]	●	●	●	●	●
SMES1 [Battery management electronics]	●	●	●	●	●
SMES2 [Battery management electronics]	●	●	●	●	●

SME 82	●	●	●	●	●
SMF [Easy entry, driver]	●	●	●	●	●
SMF [Seat memory, driver]	●	●	●	●	●
SMFA [Seat module, driver]	●	●	●	●	●
SMFAH [Seat module, rear driver's side]	●	●	●	●	●
SMFAH [driver's seat module]	●	●	●	●	●
SMG [Transmission control]	●	●	●	●	●
SPMBT [Mirror memory, front passenger]	●	●	●	●	●
SPMFT [Mirror memory, driver]	●	●	●	●	●
SPNMHL [Rear left seat inflator module]	●	●	●	●	●
SPNMHR [Rear right seat inflator module]	●	●	●	●	●
SPNMVL [Front left seat inflator module]	●	●	●	●	●
SPNMVR [Front right seat inflator module]	●	●	●	●	●
SRSNVL [Side radar sensor near range front left]	●	●	●	●	●
SRSNVR [Side radar sensor near range front right]	●	●	●	●	●
SSBF [Satellite, seat, passenger]	●	●	●	●	●
SSFA [Satellite, seat, driver]	●	●	●	●	●
SSH [Rear seat satellite]	●	●	●	●	●
STH [Indep./aux. heater]	●	●	●	●	●
STML [Headlight driver module, left]	●	●	●	●	●
STMR [Headlight driver module, right]	●	●	●	●	●
STVL [Door satellite, front left]	●	●	●	●	●
STVR [Door satellite, front right]	●	●	●	●	●
SVA [Side View Assist]	●	●	●	●	●
SVS [Speech processing]	●	●	●	●	●
SVT [Servotronic]	●	●	●	●	●
SWE [Headlight electronics]	●	●	●	●	●
SWTUDS	●	●	●	●	●
SWW [Lane Change Warning]	●	●	●	●	●
SZL [Steering column switch cluster]	●	●	●	●	●
SZM [Centre console control panel]	●	●	●	●	●
TBX [Touchbox]	●	●	●	●	●
TCB [Telematic Communication Box]	●	●	●	●	●
TCM [Hybrid gearbox control unit]	●	●	●	●	●
TCU [Telematics control unit (I-bus)]	●	●	●	●	●
TCU [Telematics control unit]	●	●	●	●	●
TEL [Eject box/Interface telephone]	●	●	●	●	●
TEL [Telephone ECE]	●	●	●	●	●
TEL [Telephone USA]	●	●	●	●	●
TFE [Hybrid pressure refuelling electronic control unit]	●	●	●	●	●
TFE [Pressurized fuel tank control module]	●	●	●	●	●
TLC [Lane departure warning]	●	●	●	●	●
TM [Telematics]	●	●	●	●	●
TMBF [Door module, front passenger door]	●	●	●	●	●
TMBF [Door module, passenger]	●	●	●	●	●
TMBFH [Door module, rear passenger's side]	●	●	●	●	●
TMFA [Door module, driver]	●	●	●	●	●
TMFA [Driver's door module]	●	●	●	●	●
TMFAH [Rear driver's side door module]	●	●	●	●	●
TMODE	●	●	●	●	●

TOENS [Thermal oil-level sensor]	●	●	●	●	●
TOP-DSP [Digital sound processor]	●	●	●	●	●
TOP-DSP2 [Digital sound processor]	●	●	●	●	●
TRS [Electronic battery isolating switch]	●	●	●	●	●
TR SVC [All-round vision camera]	●	●	●	●	●
T_AUSB	●	●	●	●	●
T_GRTB	●	●	●	●	●
T_MSA	●	●	●	●	●
T_PCOD	●	●	●	●	●
T_SCOD	●	●	●	●	●
ULF [Universal charger and hands-free unit]	●	●	●	●	●
ULF-SBX [Interface box]	●	●	●	●	●
ULF-SBX-H [Interface box High]	●	●	●	●	●
URS [Rollover sensor]	●	●	●	●	●
UTILITY	●	●	●	●	●
VDM [Vertical Dynamics Management]	●	●	●	●	●
VDP [Vertical dynamics platform]	●	●	●	●	●
VIP [Virtual integration system]	●	●	●	●	●
VIRTSG90	●	●	●	●	●
VIRTSG91	●	●	●	●	●
VIRTSG92	●	●	●	●	●
VIRTSG93	●	●	●	●	●
VIRTSG98	●	●	●	●	●
VIRTSG9B	●	●	●	●	●
VM [Video module TV]	●	●	●	●	●
VM [Video module hybrid]	●	●	●	●	●
VM [Video module]	●	●	●	●	●
VM [Video switch]	●	●	●	●	●
VM-GT [Video module, graphics stage]	●	●	●	●	●
VO	●	●	●	●	●
VS [Video switch]	●	●	●	●	●
VSG [Vehicle Sound Generator]	●	●	●	●	●
VSG2 [Vehicle Sound Generator 2]	●	●	●	●	●
VSW [Video switch]	●	●	●	●	●
VTC [Valvetronic, bank 1]	●	●	●	●	●
VTC2 [Valvetronic bank 2]	●	●	●	●	●
VTG [Transfer box]	●	●	●	●	●
W2V	●	●	●	●	●
WIM [Wiper module]	●	●	●	●	●
X_K001	●	●	●	●	●
X_KS01	●	●	●	●	●
ZBM [Two-battery management]	●	●	●	●	●
ZCS_ALL	●	●	●	●	●
ZFE [Central chassis electronics]	●	●	●	●	●
ZGM [Central gateway module]	●	●	●	●	●
ZGM2 [Central gateway module 2]	●	●	●	●	●

RollsRoyce EPB Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	EPB
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

EPB Function List

Workshop mode, Automatic Hold brake

Automatic Hold brake: Activate/Deactivate workshop mode

Automatic Hold brake: Start-up

Bedding-in workshop

EMF start-up

EMF: Bedding-in procedure

EMF: Start-up, Automatic Hold brake

EMF: Workshop mode

EMF: Workshop mode, Automatic Hold brake

Parking brake: Bedding-in procedure

Parking brake: EMF start-up

Parking brake: Initial operation

Parking brake: Workshop mode

Start-up, Automatic Hold brake

Workshop mode, Automatic Hold brake

RollsRoyce OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	OIL
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

OIL Function List

CBS Service Inclusive selection

CBS reset

CBS reset KWP

CBS reset UDS

CBS reset, engine oil

Initialisation of CBS after changing the engine control unit

Reset Service interval display

Resetting the oil service interval

RollsRoyce BMS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	BMS
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

BMS Function List

Auxiliary battery (24 V EPS): Register battery exchange

Auxiliary battery and cut-out relay

Auxiliary battery: Register battery replacement

Charging battery

Composition of the high-voltage battery unit: Read out serial numbers

High-voltage battery unit: Drain coolant expansion tank

High-voltage battery unit: Read out stored series numbers

High-voltage battery unit: Release of the coolant pump after programming

High-voltage battery: Evaluating the battery state of charge

Load starter battery and system battery.

Register battery exchange

Register battery replacement

Reset ZBM / SEC workshop mode

Starting up the high-voltage battery unit

RollsRoyce DPF Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	DPF
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

DPF Function List

Diesel particulate filter: - Request regeneration

Diesel particulate filter: Regeneration

Diesel particulate filter: Replacement

Diesel particulate filter: register replacement

RollsRoyce ECM Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	ECM
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

ECM Function List

Activating teach-in for angular offset between crankshaft and camshaft

Activation of electric fuel pump control electronics

Activation, fuel pre-supply pump

Adaptation of the increment wheel

Adaptation value for resetting the fuel pump

Adjusting the starting torque

Adjustment, consumption calculation

Adjustment, fuel consumption display

CBS functionality, engine oil impaired

CO adjustment

Check transmission oil level

Checking increment wheel adaptation

Checking the locking status of the engine control unit

Consumption calculation

Consumption calculation adjustment

DME: Clear adaptations

DME: Delete adaptations

DME: Reset adaptation values and versions

Deactivation, engine oil

Delete engine adaptation value

Deleting engine adaptation values

Determining the injectors

Engine control unit: CCM history memory

Engine control: Consumption calculation

Engine control: Mean quantity adaptation

Engine operating values record

Engine self-learning cycle

Fault elimination CBS reset engine control unit

Fuel consumption display

Fuel consumption display adjustment

Fuel consumption display correction

Fuel grade output

Fuel grade recognition

Fuel quality recognition
Increase idle speed temporarily
Mean quantity adaptation
Minimum stroke adjustment
Nitrogen oxide catalytic converter: Replacement
OBD Readiness Codes
Operational smoothness measurement
Power Down command
Power-down command
Preheating control adjustment
Rail pressure regulating valve adaptation
Register teach acceleration sensor
Reset adaptation values
Reset production mode
Reset production mode, preheating control unit
Reset rail pressure control mode
Reset speedmarks
Reset starter lock
Reset the adaptation of the electric fuel pump
Reset the production mode for the fuel pump control module
Service function, engine exchange
Start-up of fuel pump control electronics
Starting torque adjustment
engine oil level check

RollsRoyce ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	ETC
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

ETC Function List

Adaptation, hot film air mass meter

Adjusting the electromotive throttle controller

DME: Delete adaptation variable camshaft timing control

Learn Valvetronic limit positions

Learning Valvetronic limit positions

Mass meter

Open global VTC limit position adaptation

Remove Valvetronic servomotor

Reset engine adaptation values/delete variants

VANOS adaptation

Valvetronic adaptation limit positions

Valvetronic: Initial operation

Valvetronic: Start-up

RollsRoyce IDL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	IDL
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

IDL Function List

Adjust idle speed

Adjustment of idle speed

Idle speed

Idle speed adjustment

Idle speed: Target value and actual value comparison

Idling quality

RollsRoyce INJ Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	INJ
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

INJ Function List

Basic injection rate at start

Injection deactivation

Injection quantity compensation

Injection quantity compensation, 4-cylinder engine

Injector classification adjustment

No injection quantity compensation required

Reset correction values of injectors

injection quantity compensation

RollsRoyce MIS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	MIS
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

MIS Function List

ACC sensor: Function test of heater

ACC sensor: Start-up

ACC: Adjust short-range sensors

ACSM: Read coding data

Activate SDARS

Activation/deactivation terminal 15

Activation/deactivation, terminal 15

Adaptation of exhaust gas pressure sensor before exhaust turbocharger

Adaptation of screen dimensions of the reversing camera on the MASK

Adaptations and equipment specifications

Add production date

Adjust ACC sensor

Adjusting the installation position of exhaust gas restriction flap

Adjusting the wastegate linkage

All-round vision camera teach-in

Bleed headlight cleaning system

CAS: Reset

CTM: Rear module emergency access

Calibration of body general module

Calibration run for flap motors

Check Control messages

Compare equipment specification

Coolant compressor infeed protection

Correct M-ASK tuner

DWA activation

DWA: Check by false alarm (with CA)

DWA: Microwave sensors

DWA: Read or delete alarm memory

DWA: triggering

EGR adaptation

EHC safety shut-off

EHC: - Lifting and lowering function check

EHC: - Warning lamp, pre-drive check (10s)

EHC: Delete energy saving mode
EHC: Ride height sensors
EHC: Warning lamp, pre-drive check (30s)
EWS key status
EWS write key variant
Electronic immobiliser (EWS): Reset starter lock
Electronic ride height control (EHC): - Ride height sensor check
Electronic ride height control (EHC): Check ride height sensors
Electronic ride height control (EHC): Check, compressor relay
Electronic ride height control (EHC): Ride height sensors
Electronic ride height control (EHC): Vehicle level
Enable airbag activation after programming operation
Exhaust-gas recirculation
Exhaust-gas recirculation cooler adaptation
Floating headlining installation position
Glow element adjustment
HCP: Teach in tilt sensor
HSR functional check
HSR start-up
HSR wheel alignment
Head unit reset
Initialisation of the component protection in the head unit
Initialise ACC sensor
Initialise power window drive
Initialise rain/driving lights sensor.
Initialise slide/tilt sunroof
Initialise slide/tilt sunroof.
Initialising the CID cover
Initialising the radiator emblem
Instrument cluster: Control unit self-test
Integration level
Interior light autoaddressing
KAFAS: Calibration
KAFAS: Reset calibration
Navigation system: DVD lock
Newly address the air distribution flap motors
Open tailgate
Operational parameter of evaporator temperature
Radiator emblem installation position
Rain sensor initialisation
Read MRS coding data
Read out LCM operating data
Read the Check Control history memory
Remote door lock activations
Remote door unlock activations
Reset EWS
Reset EWS function
Reset fault lockout
Reset running-in check
Reset the internal ELV fault counter
Reset: SCR switch-off scenario
Ride height sensor check
Run-in protection for A/C compressor
SCR catalytic converter: register replacement

SCR control unit: Reset assembly mode
SCR reset
Seat standardisation, driver's seat
Set installation position of the EGR valve
Setting, LRR sensor for ACC
Shock absorber adjustment
Solenoid valve check
TLC: Calibrate vibration motor
Teach Touch Command snap-in adapter
Teach in front light electronic turn signal
Teach-in the exhaust flap or move it into the installation position
Tuner, New Zealand
VDM: Vertical acceleration sensor adjustment
Wastegate valve controller: Teach-in end stops/adjust wastegate linkage
Wiper: Installation position
initialise CID cover
initialise radiator emblem

RollsRoyce SAS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	SAS
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

SAS Function List

ABS/DSC sensors/steering angle sensor

ARS: Lateral acceleration sensor

Adjustment of steering angle sensor in the SZL

Adjustment of steering torque sensor

CIM: Steering column calibration

DSC: Angular rate sensor

DSC: Lateral acceleration sensor

DSC: Steering angle sensor adjustment

ELV: Partial standardisation

ELV: Standardisation

EPS: Active steering teach-in procedure

EPS: Steering start-up

EPS: Teach-in end stop

Electrical steering column adjustment standardisation

Lateral acceleration sensor

Normalisation, steering column adjustment

PSC adjustment

SZL: Steering angle sensor adjustment

Start-up Active Steering

Start-up of active steering

Steering angle sensor

Steering angle sensor adjustment

Steering angle sensor, energy saving mode

RollsRoyce TCM Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	TCM
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

TCM Function List

Coasting: System check

EGS: Learn parking

EGS: Mechatronic calibration

EGS: Reset adaptation values

EGS: transmission fluid adjustment

EME: Check 2-speed manual gearbox wear

EME: Read out the adjustment value of the rotor position sensor

EME: Reset vacuum pump operating time

Gearshift speed control

LDM: Pump motor calibration

LDM: Ventilation

MSA: Deactivate installation mode

MSA: Starter exchange

Oil change

Oil-level adjustment

Reset learning functions

Reset service function of learning functions

Service function, display and reset adaptation values

Transfer box (VTG): Calibration

Transfer box (VTG): Oil change

Transfer box (VTG): Replace control unit

Transfer box: Oil change

Transmission control unit: Display and reset adaptation values

Transmission control unit: Oil balancing

Transmission control unit: Oil change

Transmission control unit: Oil-level adjustment

Transmission control unit: Reset adaptation values

Transmission control unit: Reset learning function

Transmission control unit: Resetting adaption functions

Transmission control unit: Standstill adaption

Transmission control unit: Testing the integrated electrical pump

Transmission oil pump activation

Twin-clutch gearbox: , parking lock hook test

Twin-clutch gearbox: Functional check, parking lock

RollsRoyce TPM Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	TPM
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

TPM Function List

Display of the measured data of wheel electronics

Electronic tyre pressure specification data

Lower front axle by 35 mm for camber adjustment

Service function display of measured data wheel electronics

Service function display of the measured data of wheel electronics

Service function measured data of wheel electronics

Service function measured data wheel electronics

Tyre defect indicator

Wheel electronics measured data

RollsRoyce BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	BLD
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

BLD Function List

Brake bleeding routine

Brake line mix-up test

Braking brake bleeding procedure

Connection, brake lines

DSC unit: Brake system ventilation

DSC: Brake bleeding routine

DSC: Brake bleeding routine for special cases

DSC: Brake line mix-up test:

Vent brakes

RollsRoyce BSC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Series	Development code	Sales designation	BSC
Rolls-Royce	RR1	Phantom	●
Rolls-Royce	RR1	Phantom Extended Wheelbase	●
Rolls-Royce	RR11	ALL	●
Rolls-Royce	RR12	ALL	●
Rolls-Royce	RR2	ALL	●
Rolls-Royce	RR3	ALL	●
Rolls-Royce	RR31	ALL	●
Rolls-Royce	RR4	GHOST	●
Rolls-Royce	RR4	Ghost Extended Wheelbase	●
Rolls-Royce	RR5	ALL	●
Rolls-Royce	RR6	ALL	●

BSC Function List

ARS: Pressure sensor, front axle

ARS: Pressure sensor, rear axle

Adjustment of the driving dynamics sensors

Bleeding DSC hydraulics

Connection, rpm sensor

DSC control unit adjustment

DSC sensor adjustment

DSC unit adjustment

DSC: Adjustment of the driving dynamics sensors

DSC: Pressure sensor

DSC: Sensor adjustment

DSC: Start-up of DSC unit

DSC: pressure sensor adjustment

End-of-belt test, brake control not performed

ICM sensor system: Start-up

ICM: Coding

Pressure sensors

Read vehicle identification number (ABS/ASC)

SBA: Initial operation

Start-up for brake pedal travel sensor